

## Frameless Cabinet Assembly

### **Standard Base Cabinet Assembly**

\*Assembly photos follow after instructions.

#### ITEMS YOU WILL NEED:

Drill - Razor knife - Soft Cloth – Flat Screwdriver - Rubber mallet - Matching wax crayon

### Instructions

1. Unpack box/identify pieces.
2. Install locking lugs into designated holes on back and brace pieces.
3. Install metal threaded dowels into side pieces. Hand tighten with screwdriver.
4. Glue and install wooden dowels into side pieces beside metal dowels.
5. Wipe off excess glue before it dries.
6. Glue and install bottom piece onto side piece through dowels.
7. Hand tighten locking lugs with screw driver.
8. Install brace pieces onto side pieces through metal dowels.
9. Hand tighten locking lugs with screwdriver.
10. Glue and install other side piece into metal and wooden dowels.
11. Hand tighten locking lugs.
12. Install back piece onto sides and bottom into designated grooves.
13. Install seven screws through back into sides and bottom.
14. Install hinges onto doors in designated holes.
15. Determine door swing and install door onto cabinet screwing through designated holes.





